



Superconducting Integrated THz Receivers: Development and Applications

**Valery Koshelets, Andrey Ermakov, Lyudmila Filippenko,
Nickolay Kinev, Oleg Kiselev, Mikhail Torgashin,**
Kotel'nikov Institute of Radio Engineering and Electronics, Moscow, Russia

Arno de Lange, Gert de Lange
SRON Netherlands Institute for Space Research, the Netherlands

Sergey I. Pripolzin, and Vladimir L. Vaks
Institute for Physics of Microstructure, Nizhny Novgorod; Russia




Superconducting Integrated THz Receivers: Development and Applications

Outline


- **Superconducting Integrated Receiver (SIR)**
- **Flux Flow Oscillator (FFO) for the SIR**
- **TErahertz Limb Sounder (TELIS) project**
- **Results of the TELIS flights**
- **Future SIR applications**
- **Conclusion**

Superconducting Integrated Receiver (SIR) with phase-locked FFO





Internal part of the SIR Microcircuit




Nb-AlOx-Nb, Nb-AlN-NbN; $J_c = 5 - 10 \text{ kA/cm}^2$

Optionally: SIS – $J_c = 8 \text{ kA/cm}^2$; FFO + HM = 4 kA/cm^2





Nb-AlOx-Nb and Nb-AlN-NbN FFO for SIR






FFO frequency and power tuning





FFO frequency = 500 GHz






FL and PL spectra of the FFO : frequency 605 GHz; LW = 1.7 MHz; SR = 92 %




2011, September 22

Linewidth and Spectral Ratio on the FFO frequency





TELIS (Terahertz Limb Sounder)



Balloon-Borne TELIS Instrument


TELIS Objectives:

- Measure many species for atmospheric science:
ClO, BrO, O₃, HCl, HOCl, etc;
- Chemistry, Transport, Climate
- Serve as a test platform for new sensors
- Serve as validation tool for future satellite missions
- Three independent frequency channels, cryogenic heterodyne receivers:
 - 500 GHz by RAL
 - **490-630 GHz by SRON-IREE**
 - 1.8 THz by DLR (PI)







TELIS-SIR Main Parameters

Input frequency range	470 – 670 GHz
Minimum DSB noise temperature in the range	< 120 K
Output IF range	4 - 8 GHz
Spectral resolution	< 1 MHz
System stability (Allan variance)	20 s
Dissipated power (at 4.2 K stage)	< 30 mW
Operation temperature	< 4.5 K



SIR for TELIS – remote operation



Frequencies and substances selected for the first TELIS flight


##	FFO Frequency, GHz	Substances (High priority)
1	495.04	H ₂ ¹⁸ O
2	496.88	HDO
3	505.6	BrO ($\Delta T = 0.3$ K !!)
4	507.28	ClO
5	515.25	O ₂ /pointing /pressure
6	519.25	BrO ($\Delta T = 0.3$ K !!)
7	607.78	O ₃ isotopes
8	619.1	HCl (HOCl, ClO)



TELIS (Terahertz Limb Sounder)

SRON

Netherlands Institute for Space Research



TELIS-MIPAS at Esrange, Sweden;

March 2009; January 2010; March 2011

Balloon size: 400 000 m³; Payload weight: 1 200 kg

Altitude: 40 km (max); Duration: 12 hours



Spectra measured at limb-sounding



FFO Freq = 495 GHz

Orbit – 30 km;

Increment – 1.5 km,

Tangent: 10.5 – 30 km

45 degrees up




Down-converted Frequency, GHz

Down-converted Frequency, GHz




Second TELIS flight January 2010; Esrange, Sweden

CIO diurnal cycle



BrO

30 times averaged



Future SIR applications


New balloon missions



High-altitude airplanes



Space project "Millimetron"



Ground-space
interferometer





Medical applications





Non-invasive medical diagnostics based on analysis of exhaled air

- human exhalation contains up to 600 volatile compounds
- some of them can be used as **markers of diseases**

CO	Blood disease, asthma, oxidative stress
NO	Diseases of respiratory tract, oncology
NH₃	Diseases of gastro-enteric tract, liver, kidney
CH₄	Malabsorption of hydrocarbons
CS₂	Markers of coronary arteries diseases, schizophrenia
H₂O₂	Radiation injury, asthma



Gas Spectra Detection



Conclusion

- Concept of the **Phase-locked SIR** is developed and proven.
- **Nb-AlN-NbN** FFOs and SIRs have been successfully implemented.
- New generation of the SIR with PL FFO for **TELIS**:
Frequency range **470 – 670 GHz**; Noise temperature **< 120 K**;
IF bandwidth **4 - 8 GHz**; Spectral resolution better **1 MHz**;
System stability (spectroscopic Allan variance) **20 sec**;
Beam Pattern - **FWHM = 3 deg**, with sidelobes **< - 17 dB**.
- Procedure for **remote SIR operation** has been developed and experimentally proven.
- **3 successful TELIS flights** have been completed in March 2009, January 2010 and March 2011 at Esrange (**Kiruna, Sweden**).
- **Future space** and ground-base missions are under consideration.
- **SIR Technology** is mature enough for future space missions, non-invasive medical diagnostic, and security applications.